




	spare part no
① OVERHEAT THERMOSTAT	362415
③ RADIATION ELEMENT	369007
⑤ OUTER CYLINDER FOR BURNER	369011
⑦ GROUNDING WIRE SET	363005
⑨ FASTENING PLATE FOR T4 THERMOELEMENT	
⑪ GASKET FOR GLOW PLUG	364110
⑬ GLOW PLUG	362502
⑮ WIRE SET FOR GLOW PLUG	363052
⑰ RUBBER BUSHING	
⑲ POWER CONNECTOR, FEMALE	362304
⑳ INTERMEDIATE BLOWER	365110
㉓ FUEL PUMP, FC1	367501
㉕ FRONT PLATE FOR VENTILATION BOX	
㉗ CERAMIC PLATE WITH GASKET	368607
○	

	spare part no
② OVERHEAT. THERMOST. COMPLETE	362414
④ BURNER CYLINDER COMPLETE	369024
⑥ BOTTOM MAT, Ø 85 mm	364023
⑧ GASKET FOR T4 THERMOELEMENT	364015
⑩ T4 THERMOELEMENT + GASKET	362601
⑫ FASTENING PLATE FOR GLOW PLUG	
⑭ HOT PLATE INDICATOR LED	361020
⑯ CONTROL UNIT	361039
⑰ POWER CONNECTOR, SUPPORT PLATE	362307
⑳ COMBUSTION BLOWER	365312
㉒ HEAT EXCHANGER	
㉔ FUEL PIPE	367306
㉖ VENTILATION BOX	
○	
○	